

Premium Continuous Rim Diamond Blade



Usage ● Portable Machines- Angle Grinders
 ● Stationary Machines

Materials For use on Tiles, Fibreglass, Fibro Cement, Marble and Granite

Wheel AA Professional (Silver)

100, 115, 125, 150, 178, 200, 230mm 250, 300, 355, 400mm

Wet/Dry ● ● ● ● ● ● ● ● ● ●



Blade must be fitted closely on spindle between straight, clean, equal-sized flanges. Turn by hand to check concentric rotation. Always use safety goggles, ear protection & protective clothing. Do not force blade. Do not side-grind. Forcing/twisting will cause bluntness, increased wear, overheating, distortion and segment damage. Cool the blade by free-running in mid-air.